



## Fill Pot, Oxygen Cylinder

Flotec's Oxygen Cylinder Fill Pot provides for a vertically directed release of high-pressure gas in the event of cylinder rupture during cascade transfilling. Manufactured from the highest quality materials, our fill pots employ a solid water jacket barrier between the inner cylinder shell and outer casing.



- 3003 H-22 Tread Plate Aluminum Shell, water tight
- 1/2" Solid 6061-T6511 Extruded Tube
  - Removable
  - Through holes for water transfer
- Fits Aluminum Cylinder Sizes D & E
- Single and Double Fill Pots Available
- Wall mounting hardware available

### Ordering Information:

TCS-FP1	Single Cylinder Fill Pot	\$ 495.00 each
TCS-FP2	Double Cylinder Fill Pot	\$ 545.00 each